

CHE213 INNOVATION PROJECT

Presented by :
Anshika Agrawal
Tanvi Manhas
Vibhanshu
Sahil Kumar

Separation of Azeotropic Mixtures via Entrainer-Assisted Distillation

INTRO OF THE PROBLEM

Azeotropic distillation is an advanced separation method used to overcome the limitations of simple distillation when dealing with azeotropic mixtures. An azeotrope is a specific composition of two or more substances that boil at a constant temperature, producing vapor with the same composition as the liquid mixture. This phenomenon prevents complete separation by conventional distillation.

OBJECTIVE


This experiment aims to investigate the separation of ethanol-water azeotropic mixtures using both simple distillation and azeotropic distillation. The study also explores the effect of using glycerol as a separating agent to break the azeotrope and improve ethanol recovery.



EXPERIMENTAL SETUP

- **Boiling Flask:** Contains the ethanol–water mixture; heated with a mantle or hot plate.
- **Distillation Column:** Allows vapor to rise and partially separate components based on volatility.
- **Thermometer:** Positioned at the top to monitor vapor temperature during distillation.
- **Condenser:** Cools and condenses vapor into liquid using circulating cold water.
- **Receiver Flask:** Collects the condensed distillate.
- **Glycerol Addition:** 60 mL glycerol added to 100 mL feed mixture for azeotropic distillation with entrainer.
- **Cooling System:** Provides a steady flow of cold water to the condenser.
- **Refractometer:** used to measure the refractive index of a liquid.





INNOVATION ASPECT

- The innovation in this experiment lies in the use of glycerol as a separating agent to break the ethanol–water azeotrope. Unlike conventional entrainers, glycerol is non-volatile, safe, and environmentally friendly.
- Its high boiling point alters the vapor–liquid equilibrium of the azeotropic mixture, allowing ethanol to be distilled at a higher purity than the typical 95.6% limit. This approach enhances ethanol recovery without requiring major modifications to standard distillation equipment, offering a practical, cost-effective, and sustainable method for azeotrope separation.

METHODOLOGY

Procedure:

It focuses on how the distillation process is conducted, including how the mixtures are heated, how samples are taken, and how the refractive index is measured.

- Place the mixture in a boiling flask and heat it.
- Wait until the top and bottom temperatures stabilize.
- Take samples from both the top and bottom every 3 minutes.
- Use a refractometer to measure the refractive index of the samples and record the temperatures.
- Repeat for all mixture compositions.



METHODOLOGY

For azeotropic distillation without glycerol

A : 98:2 % EtOH : H₂O (by volume)

B : 89.5 :10.5 % EtOH : H₂O (by volume)

C : 50:50 % EtOH : H₂O (by volume)

D : 25:75 % EtOH : H₂O (by volume)

With glycerol (total volume – 160 ml)

A : 98 ml EtOH, 2 ml H₂O, 60 ml Glycerol

B : 89.5 ml EtOH, 10.5 ml H₂O, 60 ml Glycerol

C : 50 ml EtOH, 50 ml H₂O, 60 ml Glycerol

D : 25 ml EtOH, 75 ml H₂O, 60 ml Glycerol



THEORY


Azeotropic distillation is a specialized method used to separate liquid mixtures that form azeotropes—compositions that boil at a constant temperature and behave like a single substance during boiling. In the case of ethanol and water, they form a minimum-boiling azeotrope at around 95.6% ethanol by volume. At this point, both the vapor and liquid have the same composition, making it impossible to separate them further using regular distillation.

Without Glycerol:

- When an ethanol–water mixture near the azeotropic point is distilled, no further purification beyond 95.6% ethanol is possible because the vapor and liquid remain identical in composition. This is the limitation of simple azeotropic distillation.

With Glycerol (Entrainer):


- To break this azeotrope, glycerol—a high-boiling, polar liquid—is added. Glycerol interacts more strongly with water than with ethanol, effectively reducing the water's tendency to evaporate. This change shifts the vapor–liquid equilibrium, allowing ethanol to become the more volatile component. As a result, ethanol can be distilled at a higher purity. Since glycerol has a very high boiling point ($\sim 290^{\circ}\text{C}$), it stays in the flask and can be reused in further distillations.



RESULTS

1: Calibration Data – Ethanol-Water Mixture

- Due to the absence of precise calibration data, we used the known feed compositions and corresponding refractive index (RI) values to generate a linear calibration curve. This approach is supported by literature, which suggests that ethanol-water mixtures exhibit a linear relationship between composition and RI. Our previous experiments with ethyl acetate and acetonitrile also followed this trend.
- The linear calibration fit is given by:





$$v_{\text{EtOH}} = 4719.80 \times \text{RI} - 6338.31$$

2: T-x-y Plot for Ethanol-Water Mixture

To model the vapor-liquid equilibrium for ethanol and water, quadratic fits were applied to the temperature-composition data:

- Tx (Liquid line): $T = 64.63 \cdot x^2 - 86.04 \cdot x + 100$
- Ty (Vapor line): $T = 75.24 \cdot y^2 - 96.83 \cdot y + 100$






3: Calibration Data – Ethanol–Water–Glycerol mixture

Specific calibration data for ethanol–water–glycerol mixtures were not available. However, literature showed that RI–composition relationships in ternary mixtures involving glycerol tend to follow a polynomial trend. Based on this, we fit a second–degree polynomial to our measured data:

$$v = 1,165,894.36 \cdot RI^2 - 3,274,610.02 \cdot RI + 2,299,359.46$$

4: T-x-y Plot for Glycerol System

Due to limited vapor phase data for ternary mixtures, the ethanol-water azeotrope equilibrium curves were used for comparison:



Tx (Bubble line): $T = 64.63 \cdot x^2 - 86.04 \cdot x + 100$

ANALYSIS

Negative Volume Readings

Some data showed negative or inaccurate volume values. Possible causes include:

- **Calculation errors:** Indirect calculations led to incorrect derived volumes.
- **Measurement issues:** Manual volume readings may have been inconsistent or incorrect.
- **Evaporation or leaks:** Loss of vapor during distillation reduced collected volumes.
- **Incorrect baselines:** Failing to properly tare or note flask volumes resulted in faulty data.



Sources of Deviation

- **Lack of calibration curves:** Without accurate RI-to-concentration mapping, ethanol content estimation was imprecise.
- **Heating inconsistencies:** Fluctuating temperatures affected the stability of the distillation process.
- **Poor mixing:** Glycerol may not have fully mixed with the ethanol-water feed, affecting uniformity.
- **Vapor loss:** Inefficient condensation or minor leaks led to loss of volatile components.
- **Low column efficiency:** The simple lab-scale setup lacked the precision of industrial or packed columns, reducing separation effectiveness.

SAMPLE	AVG TEMP (Ty)	MOL FRACTION OF ETHANOL IN VAPOR PHASE(X)
A	77.45	-0.4852
B	77.7	-0.4851
C	78.1	-0.4860
D	78.025	-0.4862



CONCLUSION

- Glycerol addition showed some improvement in separating the ethanol–water azeotrope but did not achieve the expected ethanol purity.
- The absence of accurate calibration data (refractive index vs. ethanol concentration) limited the precision of composition analysis.
- Observed deviations indicate the need for:
 - Better process control
 - Improved calibration methods
 - A more efficient distillation setup for enhanced separation and accuracy

FUTURE WORK

- Develop an accurate calibration curve for refractive index versus ethanol mole fraction to improve composition analysis.
- Ensure thorough mixing of the feed to achieve uniform distribution of glycerol.
- Use more precise equipment for volume measurements to reduce manual errors.
- Maintain controlled and steady heating to minimize bumping and vapor losses.
- Upgrade to a fractional distillation column to enhance separation efficiency.
- Properly seal and insulate the apparatus to avoid heat and vapor losses.
- Tare and document flask volumes accurately before and after each run to ensure correct volume tracking.



THANK YOU